


PLAN VIEW

SHOWING PRE-FORMED DETECTOR LOOP ARRANGEMENT



PROFILE VIEW

SHOWING DETECTOR FEEDER PIPE INSTALLATION FOR PRE-FORMED LOOPS

NOTES:

1. TERMINATE DETECTOR CONDUIT 300 mm ABOVE FINISHED GRANULAR BASE PRIOR TO FINAL BASE COURSE COMPACTION, INSTALL PLASTIC PLUGS.
2. PLACE PRE-FORMED LOOPS AND ASSOCIATED HOME RUN LEADS IN PLACE AFTER FINAL BASE COURSE COMPACTION AND FORMWORK. AFFIX IN PLACE USING STAPLES.
3. TRIM THE LOOP DETECTOR CONDUIT BELOW PROPOSED PAVEMENT WHEN INSTALLING HOME RUN LEAD WIRES FROM PRE-FORMED LOOPS.

DIMENSIONS ARE IN MILLIMETRES
(UNLESS OTHERWISE NOTED)

Revisions		Reference Spec. No.		Scale:	
		CW 3620		N.T.S.	
		Designed By:	Drawn By:	Drawing No.	
		N.K.B.	B.H.	SD-334	
		Checked By:	Date:		
		N.K.B.	01/04/11		
		Approved:			
No.	Date	Description			
2	12/11/14	REVISED BY DILLON CONSULTING			
1	01/04/11	REVISED TO SIGNALS SPEC/CAD FILE			

THE CITY OF WINNIPEG
PUBLIC WORKS DEPARTMENT

VEHICLE DETECTOR LOOPS
-PRE-FORMED